



Indications: Ankle sprain, Grade 1

- Measure and size accordingly
- Stretch the ends
- Apply cool water and towel out
- Pull relax and roll bandage with 50-50 coverage
- Hold and mold with palms only
- Position as prescribed by physician
- Trim fiberglass, then stretch both ends of the splint to create space for heel
- Pad bony prominences