



Indications: Sprains, Lacerations

- Measure and size accordingly
- Stretch the ends
- Apply cool water and towel out
- Pull relax and roll bandage with 50-50 coverage
- Hold and mold with palms only
- Position as prescribed by physician
- Position at approximately 45 degrees
- Remove tape before discharge